



TRANSITION SUBS



Transition subs connect directly between the drill pipe and the housing or backreamer. The overall length of the transition sub allows you to pull into the machine wrenches to make up or break loose from the drill pipe.

PART NUMBERS	DESCRIPTION	MODEL(S)
400-1260	1.10 M / 1.10 M	JT5
369-213	1.21 M / 1.21 F	JT520
369-326	1.41 M / 1.41 F	JT920 / JT920L / JT921 / JT922
400-2217	1.41 M / 2.0 M API IF	JT920 / JT920L / JT921 / JT922
400-1427	1.30 M / 1.41 F	JT922 Coarse Thread / JT9 / JT10
400-2216	1.30 M / 2.0 M API IF	JT922 Coarse Thread / JT9 / JT10
401-005	1.47 M / 1.94 M	JT1220M1
400-2193	1.47 M / 2.0 M API IF	JT1220M1
368-985	1.69 M / 1.69 F	JT1720M1
400-2747	1.76 M / 2.38 M API R	JT24
400-2202	1.94 M / 2.0 M API IF	JT20 / JT2020 / JT20XP
400-2192	1.94 M / 2.38 M API R	JT20 / JT2020 / JT20XP
401-319	1.94 M / 1.94 M	JT20 / JT2020 / JT20XP
400-231	2.11 M / 2.59 M	JT25 / JT2720M1 / JT3020 / JT30
400-2191	2.11 M / 2.38 M API R	JT25 / JT2720M1 / JT3020 / JT30
400-2466	2.10 M / 2.88 M API R	JT40
400-575	2.59 M / 2.59 M	JT4020M1
400-1419	2.59 M / 2.88 M API R	JT4020M1
400-2268	2.46 M / 3.27 M	JT60
400-2269	2.46 M / 2.88 M API R	JT60
400-1479	3.27 M / 3.5 M API IF	JT7020 / JT8020 / JT100
369-222	3.27 M / 3.27 M	JT7020 / JT8020 / JT100

ALL TERRAIN TRANSITION SUBS

All Terrain transition subs allow you to run dirt tooling with the patented All Terrain Power Pipe®.



PART NUMBERS	DESCRIPTION	MODEL(S)
400-057	2.52 M / 2.59 M	AT2720 / AT30
369-410	2.77 M / 2.59 M	AT2720 / AT30
400-2305	2.77 M / 2.38 M API R	AT30
400-2709	2.95 M / 2.59 M	AT40
400-2465	2.95 M / 2.88 M API R	AT40
400-2684	2.95 M / 3.50 M API IF	AT40
400-2710	2.95 M / 3.27 M API R	AT40
400-685	3.25 M / 2.59 M	AT4020
400-1679	3.25 M / 2.88 M API R	AT4020 / AT60
401-143	3.25 M / 3.27 M	AT4020 / AT60
400-1383	3.44 M / 3.27 M	AT100
400-1678	3.44 M / 3.5 M API IF	AT100
400-3077*	2.95 M / 3.25 F	AT40

*Note: 400-3077 is a dual rod transition sub.

ALL TERRAIN CONNECTORS

Featuring a compact design, All Terrain connectors allow you to run dirt tooling with the patented All Terrain Power Pipe®.



PART NUMBERS	DESCRIPTION	MODEL(S)
400-2766	2.77 M / 2.88 M API R	AT30
400-2767	2.77 M / 3.5 M API IF	AT30
400-2768	2.95 M / 2.88 M API R	AT40
400-2769	2.95 M / 3.5 M API IF	AT40
400-2770	3.25 M / 2.88 M API R	AT60
400-2771	3.25 M / 3.50 M API IF	AT60
400-2772	3.44 M / 2.88 M API R	AT100
400-2773	3.44 M / 3.5 M API IF	AT100

HDX/HIWS1/HXT™ TRANSITION SUBS

No matter what drill pipe you run on your rig, we build compatible starter rods to give you the genuine Ditch Witch® performance you expect.

PART NUMBERS	DESCRIPTION	MODEL(S)
400-2294	#200 M / #200 M	JT520 / JT5
400-2293	#200 M / 1.10 M	JT520 / JT5
400-2284	#200 M / 2.0 M API IF	JT920 / JT921 / JT922
400-2285	#200 M / 1.94 M	JT920 / JT921 / JT922
400-2286	#200 M / 1.41 F	JT920 / JT921 / JT922
400-2289	#250 M / 2.0 M API IF	JT1220M1
400-2290	#250 M / 1.94 M	JT1220M1
400-2282	#400 M / 1.94 M	JT1220M1 / JT20
400-2278	#400 M / 2.0 M API IF	JT1220M1 / JT20
400-2279	#400 M / 2.38 M API	JT1220M1 / JT20
400-2283	#600 M / 1.94 M	JT20 / JT2020
400-2244	#600 M / 2.38 M API R	JT2020 / JT20 / JT25 / JT3020 / JT30
400-2245	#600 M / 2.59 M API R	JT2020 / JT20 / JT25 / JT3020 / JT30
400-2246	#600 F / 2.59 M API R	JT25
400-2685	#700 M / 2.88 M API R	JT40
400-2271	#900 M / 3.27 M	JT60
400-2272	#900 M / 2.88 M API R	JT60
400-2258	#800 M / 3.27 M	JT7020 / JT8020 / JT100
400-2257	#800 M / 3.5 M API IF	JT7020 / JT8020 / JT100
908-0802	#200 F / 2.11 M	D6X6 / D7X11 / D9X13
908-1702	#250 F / 2.38 M API R	D16X20
908-1705	#400 F / 2.38 M API R	D18X20 / D20X22 / D24X26
908-4227	#402 F / 2.38 M API R	D24X33
908-4223	#600 F / 2.38 M API R	D24X40
908-4229	#602 F / 2.38 M API R	D33X44 / D36X50 (#602)
908-4230	#650 F / 2.38 M API R	D33X44 / D36X50 (#650)
908-4241	#700 F / 2.38 M API R	D36X50 (#700)
908-4240	#702 F / 2.38 M API R	D36X50 (#702)
908-5187	#800 F / 2.88 M API R	D50X100 / D55X100 / D75X100 / D80X100
908-5198	#800 F / 3.50 M API R	D80X120 / D100X120 (#1000)
908-5194	#802 F / 2.88 M API R	D80X120 / D100X120 (#802)
908-5204	#802 F / 3.50 M API R	D80X120 / D100X120 (#802)
908-5185	#900 F / 2.88 M API R	D50X100 / D80X100
908-5201	#900 F / 3.50 M API R	D50X100 / D80X100
908-5206	#1000 F / 3.50 M API R	D80X120 / D100X120 (#1000) / DD110





NO HEAVY TOOLS.
NO HASSLES.

Modern directional drilling rigs have greater torque and pullback forces, requiring increased control over HDD tooling and backreamers. Made for today's most powerful drills, the Hawkeye® quick connect system can withstand greater torque and pullback forces while improving steering control and extending tool life.

EZ CONNECT ASSEMBLIES

DITCH WITCH® THREAD

In addition to providing all the benefits of a transition sub, EZ Connect assemblies offer a quick method of changing out tooling without using the machine torque or quick wrenches.

PART NUMBERS	THREAD	DESCRIPTION	MODEL(S)
400-1261	1.10 M / 1.31 M EZ2	EZ Connect Assembly	JT5
400-1259		Transition Sub	
149-104		O-Ring	
369-258		Collar	
107-519		Retainer Bolt	
400-1384	1.3 M / 1.63 M EZ2	EZ Connect Assembly	JT922 Coarse Thread / JT9 / JT10
400-1178		Transition Sub	
149-911		O-Ring	
400-1860		Collar	
107-540		Retainer Bolt	
401-300	1.94 M / 2.0 M EZ2	EZ Connect Assembly	JT2020 / JT20
401-301		Transition Sub	
157-194		O-Ring	
400-1862		Collar	
107-521		Retainer Bolt	
400-2746	1.76 M / 2.0 M EZ2	EZ Connect Assembly	JT24
400-2745		Transition Sub	
157-194		O-Ring	
400-1862		Collar	
107-521		Retainer Bolt	
400-1507	2.77 DS / 2.25 M EZ3	EZ Connect Assembly	AT2720 / AT30
400-1506		Transition Sub	
149-548		O-Ring	
400-1864		Collar	
106-847		Retainer Bolt	
316-573		Inner Rod Support Block	
400-2462	2.10 M / 2.63 EZ2	EZ Connect Assembly	JT40
400-2461		Transition Sub	
149-041		O-Ring	
400-1865		Collar	
107-513		Retainer Bolt	
400-2464	2.95 M / 2.85-6 M EZ2	EZ Connect Assembly	AT40
400-2463		Transition Sub	
400-2391		Collar	
155-703		O-Ring	
155-074		Retainer Bolt	
400-2393	2.46-4 M / 2.85-6 M EZ2	EZ Connect Assembly	JT60
400-2389		Transition Sub	
155-703		O-Ring	
400-2391		Collar	
155-074		Retainer Bolt	
400-1674	3.27 M / 3.5 M EZ2	EZ Connect Assembly	JT8020M1 / JT100M1
400-1481		Transition Sub	
149-042		O-Ring	
368-815		Collar	
105-593		Retainer Bolt	



EZ CONNECT ASSEMBLIES*LEGACY

DITCH WITCH® THREAD

PART NUMBERS	THREAD	DESCRIPTION	MODEL(S)
400-105	1.21 M / 1.31 M EZ2	EZ Connect Assembly	JT520
400-104		Transition Sub	
149-104		O-Ring	
369-258		Collar	
107-519		Retainer Bolt	
400-070	1.41 M / 1.63 M EZ2	EZ Connect Assembly	JT920 / JT920L / JT921 / JT922 Fine Thread
400-067		Transition Sub	
149-911		O-Ring	
400-1860		Collar	
107-540		Retainer Bolt	
400-918	1.47 M / 1.88 M EZ3	EZ Connect Assembly	JT1220M1
400-917		Transition Sub	
153-856		O-Ring	
400-1861		Collar	
106-847		Retainer Bolt	
400-001	1.69 M / 2.0 M EZ2	EZ Connect Assembly	JT1720M1
369-998		Transition Sub	
157-194		O-Ring	
400-1862		Collar	
107-521		Retainer Bolt	
369-814	2.11 M / 2.25 M EZ2	EZ Connect Assembly	JT2720M1
369-812		Transition Sub	
149-548		O-Ring	
400-1863		Collar	
107-521		Retainer Bolt	
400-095	2.59 M / 2.63 M EZ2	EZ Connect Assembly	JT4020M1
400-096		Transition Sub	
149-041		O-Ring	
400-1865		Collar	
107-513		Retainer Bolt	

Note: EZ3 are designed for the JT1220 and JT25/30 only.



EZ CONNECT ASSEMBLIES

HDX/HIWS1/HXT™ THREAD

PART NUMBERS	THREAD	DESCRIPTION	MODEL(S)
400-2296	#200 M / 1.31 M EZ2	EZ Connect Assembly	JT520 / JT5
400-2295		Transition Sub	
149-104		O-Ring	
369-258		Collar	
107-519		Retainer Bolt	
400-2288	#200 M / 1.63 M EZ2	EZ Connect Assembly	JT920 / JT920L / JT921 / JT922 / JT9 / JT10
400-2287		Transition Sub	
149-911		O-Ring	
400-1860		Collar	
107-540		Retainer Bolt	
400-2281	#400 M / 2.0 M EZ2	EZ Connect Assembly	JT1220M1 / JT20
400-2280		Transition Sub	
400-1862		Collar	
107-521		Retainer Bolt	
400-2292	#250 M / 1.88 M EZ3	EZ Connect Assembly	JT1220M1
400-2291		Transition Sub	
153-856		O-Ring	
400-1861		Collar	
106-847		Retainer Bolt	
400-2251	#600 M / 2.25 M EZ3	EZ Connect Assembly	JT2020 / JT20 / JT24 / JT25 / JT3020 / JT30
400-2247		Transition Sub	
149-548		O-Ring	
400-1864		Collar	
107-277		Retainer Bolt	
400-2252	#600 F / 2.25 M EZ3	EZ Connect Assembly	JT24 / JT25
400-2248		Transition Sub	
149-548		O-Ring	
400-1864		Collar	
107-277		Retainer Bolt	
400-2687	#700 M / 2.63 EZ2	Transition Sub	JT40
400-2686		Transition Sub	
149-041		O-Ring	
400-1865		Collar	
107-513		Retainer Bolt	
400-2522	#900 M / 2.85-6 M EZ2	EZ Connect Assembly	JT60
400-2523		Transition Sub	
155-703		O-Ring	
400-2391		Collar	
155-074		Retainer Bolt	
400-2260	#800 M / 3.5 M EZ2	EZ Connect Assembly	JT8020M1 / JT100M1
400-2259	#800 M / 3.5 M EZ	Transition Sub	
368-815		Collar	
105-593		Retainer Bolt	



HAWKEYE®

DITCH WITCH® THREAD

The revolutionary Hawkeye quick connect system is made specifically for today's more powerful drilling rigs. Our patented wear compensation design provides:

- Longer tool life
- Virtually eliminates cross threading
- Compatible with any machine
- Faster make up
- Through-collar lubrication



PART NUMBERS	THREAD	DESCRIPTION	MODEL(S)
918-0734	1.41 M / HKEYE 275 F	Hawkeye 275 Starter Rod Short	JT920 / JT920L / JT921 / JT922 Fine Thread
918-0759	1.41 M / HKEYE 275 F	Hawkeye 275 Starter Rod Long	JT920 / JT920L / JT921 / JT922 Fine Thread
918-0715		Hawkeye 275 Collar	
918-0722		O-Ring	
918-0736	1.3 M / HKEYE 275 F	Hawkeye 275 Starter Rod Short	JT922 Coarse Thread / JT9
918-0760	1.3 M / HKEYE 275 F	Hawkeye 275 Starter Rod Long	JT922 Coarse Thread / JT9
918-0715		Hawkeye 275 Collar	
918-0722		O-Ring	
918-0738	1.47 M / HKEYE 275 F	Hawkeye 275 Starter Rod Short	JT1220M1
918-0761	1.47 M / HKEYE 275 F	Hawkeye 275 Starter Rod Long	JT1220M1
918-0715		Hawkeye 275 Collar	
918-0722		O-Ring	
918-2454	1.69 M / HKEYE 350 F	Hawkeye 350 Starter Rod Short	JT1720M1
918-2492	1.69 M / HKEYE 350 F	Hawkeye 350 Starter Rod Long	JT1720M1
918-2439		Hawkeye 350 Collar	
918-2423		O-Ring	
918-2495	1.76 M / HKEYE 350 F	Hawkeye 350 Starter Rod	JT24
918-2439		Hawkeye 350 Collar	
918-2423		O-Ring	
918-2453	1.94 M / HKEYE 350 F	Hawkeye 350 Starter Rod Short	JT2020M1
918-2491	1.94 M / HKEYE 350 F	Hawkeye 350 Starter Rod Long	JT2020M1
918-2439		Hawkeye 350 Collar	
918-2423		O-Ring	
918-2455	2.11 M / HKEYE 350 F	Hawkeye 350 Starter Rod Short	JT24 / JT25 / JT2720M1 / JT3020 / JT30
918-2493	2.11 M / HKEYE 350 F	Hawkeye 350 Starter Rod Long	JT24 / JT25 / JT2720M1 / JT3020 / JT30
918-2439		Hawkeye 350 Collar	
918-2423		O-Ring	
918-3049	2.11 M / HKEYE 390 F	Hawkeye 390 Starter Rod Short	JT24 / JT25 / JT2720M1 / JT3020 / JT30
918-3091	2.11 M / HKEYE 390 F	Hawkeye 390 Starter Rod Long	JT24 / JT25 / JT2720M1 / JT3020 / JT30
918-3029		Hawkeye 390 Collar	
918-3019		O-Ring	
918-2471	2.77 DS M / HKEYE 350 F	Hawkeye 350 Starter Rod	AT2720M1 / AT30
918-2439		Hawkeye 350 Collar	
918-2423		O-Ring	
918-2470	2.52 SS M / HKEYE 350 F	Hawkeye 350 Starter Rod	AT2720M1 / AT30
918-2439		Hawkeye 350 Collar	
918-2423		O-Ring	
908-3058	2.77 DS M / HKEYE 390 F	Hawkeye 390 Starter Rod	AT2720M1 / AT30
918-3029		Hawkeye 390 Collar	
918-3019		O-Ring	
918-3057	2.52 SS M / HKEYE 390 F	Hawkeye 390 Starter Rod	AT2720M1 / AT30
918-3029		Hawkeye 390 Collar	
918-3019		O-Ring	



HAWKEYE®

DITCH WITCH® THREAD

PART NUMBERS	THREAD	DESCRIPTION	MODEL(S)
918-2459	2.59 M / HKEYE 350 F	Hawkeye 350 Starter Rod Short	JT4020 / JT4020M1
918-2494	2.59 M / HKEYE 350 F	Hawkeye 350 Starter Rod Long	JT4020 / JT4020M1
918-2439		Hawkeye 350 Collar	
918-2423		O-Ring	
918-3050	2.59 M / HKEYE 390 F	Hawkeye 390 Starter Rod Short	JT4020 / JT4020M1
918-3092	2.59 M / HKEYE 390 F	Hawkeye 390 Starter Rod Long	JT4020 / JT4020M1
918-3029		Hawkeye 390 Collar	
918-3019		O-Ring	
918-3648	2.59 M / HKEYE 426 F	Hawkeye 426 Starter Rod	JT4020M1
918-3640		Hawkeye 426 Collar	
918-3619		O-Ring	
918-3074	2.10 M / HKEYE 390 F	Hawkeye 390 Starter Rod	JT40
918-3676	2.10 M / HKEYE 426 F	Hawkeye 426 Starter Rod	JT40

HAWKEYE

HDX/HIWS1/HXT™ THREAD

PART NUMBERS	THREAD	DESCRIPTION	MODEL(S)
918-0756	#200 M / HKEYE 275 F	Hawkeye 275 Starter Rod	JT5 / JT922 / JT9
918-0715		Hawkeye 275 Collar	
918-0722		O-Ring	
918-0713	#200 F / HKEYE 275 F	Hawkeye 275 Starter Rod	D6X6 / D7X11 / D9X13
918-0715		Hawkeye 275 Collar	
918-0722		O-Ring	
918-0757	#250 M / HKEYE 275 F	Hawkeye 275 Starter Rod	JT1220
918-0715		Hawkeye 275 Collar	
918-0722		O-Ring	
918-2486	#400 M / HKEYE 350 F	Hawkeye 350 Starter Rod	JT1220 / JT20
918-2439		Hawkeye 350 Collar	
918-2423		O-Ring	
918-2437	#250 F / HKEYE 350 F	Hawkeye 350 Starter Rod	D16X20
918-2439		Hawkeye 350 Collar	
918-2423		O-Ring	
918-2468	#600 M / HKEYE 350 F	Hawkeye 350 Starter Rod	JT2020 / JT20
918-2439		Hawkeye 350 Collar	
918-2423		O-Ring	
918-2489	#600 M / HKEYE 350 F	Hawkeye 350 Starter Rod Long	JT24 / JT25 / JT30
918-2439		Hawkeye 350 Collar	
918-2423		O-Ring	
918-3067	#600 M / HKEYE 390 F	Hawkeye 390 Starter Rod	JT24 / JT25 / JT30
918-3029		Hawkeye 390 Collar	
918-3019		O-Ring	
918-3043	#700 / HKEYE 390 F	Hawkeye 390 Starter Rod	JT40
918-3029		Hawkeye 390 Collar	
918-3019		O-Ring	
918-3654	#700 / HKEYE 426 F	Hawkeye 426 Starter Rod	JT40
918-3460		Hawkeye 426 Collar	
918-3619		O-Ring	



HAWKEYE® HDX/HIWS1/HXT™ THREAD

PART NUMBERS	THREAD	DESCRIPTION	MODEL(S)
918-3046	#250 F / HKEYE 390 F	Hawkeye 390 Starter Rod	D16X20
918-3029		Hawkeye 390 Collar	
918-3019		O-Ring	
918-2436	#400 F / HKEYE 350 F	Hawkeye 350 Starter Rod	D18X20 / D22X20 / D24X26
918-2439		Hawkeye 350 Collar	
918-2423		O-Ring	
918-3047	#400 F / HKEYE 390 F	Hawkeye 390 Starter Rod	D18X20 / D22X20 / D24X26
918-3029		Hawkeye 390 Collar	
918-3019		O-Ring	
918-2456	#402 F / HKEYE 350 F	Hawkeye 350 Starter Rod	D24X33
918-2439		Hawkeye 350 Collar	
918-2423		O-Ring	
918-3048	#402 F / HKEYE 390 F	Hawkeye 390 Starter Rod	D24X33
918-3029		Hawkeye 390 Collar	
918-3019		O-Ring	
918-2434	#600 F / HKEYE 350 F	Hawkeye 350 Starter Rod	JT24 / JT25 / D24X40
918-2439		Hawkeye 350 Collar	
918-2423		O-Ring	
918-3017	#600 F / HKEYE 390 F	Hawkeye 390 Starter Rod	JT24 / JT25 / D24X40
918-3029		Hawkeye 390 Collar	
918-3019		O-Ring	
918-3617	#600 F / HKEYE 426 F	Hawkeye 426 Starter Rod	JT24 / JT25 / D24X40
918-3640		Hawkeye 426 Collar	
918-3619		O-Ring	
918-2435	#602 F / HKEYE 350 F	Hawkeye 350 Starter Rod	D33X44 / D36X50
918-2439		Hawkeye 350 Collar	
918-2423		O-Ring	
918-3018	#602 F / HKEYE 390 F	Hawkeye 390 Starter Rod	D33X44 / D36X50
918-3029		Hawkeye 390 Collar	
918-3019		O-Ring	
918-3609	#602 F / HKEYE 426 F	Hawkeye 426 Starter Rod	D33X44 / D36X50
918-3640		Hawkeye 426 Collar	
918-3619		O-Ring	
918-2457	#650 F / HKEYE 350 F	Hawkeye 350 Starter Rod	D33X44 / D36X50
918-2439		Hawkeye 350 Collar	
918-2423		O-Ring	
918-3015	#650 F / HKEYE 390 F	Hawkeye 390 Starter Rod	D33X44 / D36X50
918-3029		Hawkeye 390 Collar	
918-3019		O-Ring	
918-3649	#650 F / HKEYE 426 F	Hawkeye 426 Starter Rod	D33X44 / D36X50
918-3640		Hawkeye 426 Collar	
918-3619		O-Ring	
918-2458	#700 F / HKEYE 350 F	Hawkeye 350 Starter Rod	D36X50 / D33X44 / D36X50
918-2439		Hawkeye 350 Collar	
918-2423		O-Ring	
918-3016	#700 F / HKEYE 390 F	Hawkeye 390 Starter Rod	D36X50 / D33X44 / D36X50
918-3029		Hawkeye 390 Collar	
918-3019		O-Ring	

Note: Collar and O-Ring sold separately.



HAWKEYE® REAMER COLLARS

PART NUMBERS	DESCRIPTION	SIZE
918-2488	Reamer Collar	Hawkeye 350
918-2461	Pull Tab Connector	Hawkeye 350
918-3088	Reamer Collar	Hawkeye 390
918-3054	Pull Tab Connector	Hawkeye 390



HAWKEYE SCREWS

PART NUMBERS	DESCRIPTION	SIZE
918-0618	Socket Head Cap Screw	Hawkeye 275
918-0719	Plug	Hawkeye 275
918-0718	Nozzle	Hawkeye 275
918-0001	Socket Head Cap Screw	Hawkeye 350-426
918-2419	Plug	Hawkeye 350-426
918-2418	Nozzle	Hawkeye 350-426



LPT QUICK CONNECT

Our LPT quick connects are specifically designed to fit your Vermeer® rig.

PART NUMBERS	THREAD	DESCRIPTION	MODEL(S)
400-2249	#600 M / 2.125 LPT F	2.125 LPT Starter Rod	JT25 / JT3020 / JT30
908-4244		2.125 LPT Collar	
908-0812	#200 F / 1.62 LPT F	1.62 LPT Starter Rod	D6X6 / D7X7 / D9X13
908-0844		1.62 LPT Collar	
908-0101		1.62 LPT Bolt	
908-4273	#250 F / 2.125 LPT F	2.125 LPT Starter Rod	D16X20
908-4244		2.125 LPT Collar	
908-4272	#400 F / 2.125 LPT F	2.125 LPT Starter Rod	D18X20 / D20X22 / D24X26
908-4244		2.125 LPT Collar	
908-4275	#402 F / 2.125 LPT F	2.125 LPT Starter Rod	D24X33
908-4244		2.125 LPT Collar	
908-4274	#600 F / 2.125 LPT F	2.125 LPT Starter Rod	JT24 / JT25 / D24X40
908-4244		2.125 LPT Collar	
908-4277	#602 F / 2.125 LPT F	2.125 LPT Starter Rod	D33X44 / D36X50
908-4244		2.125 LPT Collar	
908-4278	#650 F / 2.125 LPT F	2.125 LPT Starter Rod	D33X44 / D36X50
908-4244		2.125 LPT Collar	
908-4280	#700 F / 2.125 LPT F	2.125 LPT Starter Rod	D36X50
908-4244		2.125 LPT Collar	
908-0104		2.125 LPT Bolt	
908-4288	2.12 LPT	Reamer Collar	
908-4285	2.12 LPT	Pull Tab Connector	



QUICK CONNECT SYSTEMS



SPLINELOK® II

SplineLok II is the strongest non-rotational quick connect system on the market. Its patented double-pin system and its unique taper-to-taper interlock design ensure quick assembly and tooling removal.

PART NUMBERS	THREAD	DESCRIPTION	MODEL(S)
908-4271	1.69 M / SPLK 350 M	SplineLok II 350 Starter Rod Short	JT1720M1
908-4311	1.69 M / SPLK 350 M	SplineLok II 350 Starter Rod Long	JT1720M1
908-4270	1.94 M / SPLK 350 M	SplineLok II 350 Starter Rod Short	JT2020M1
908-4310	1.94 M / SPLK 350 M	SplineLok II 350 Starter Rod Long	JT2020M1
908-4318	1.76 M / SPLK 350 M	SplineLok II 350 Starter Rod Long	JT24
908-4276	2.11 M / SPLK 350 M	SplineLok II 350 Starter Rod Short	JT2020 / JT20 / JT25 / JT2720M1 / JT30M1
908-4312	2.11 M / SPLK 350 M	SplineLok II 350 Starter Rod Long	JT2020 / JT20 / JT25 / JT2720M1 / JT30M1
908-4281	2.59 M / SPLK 350 M	SplineLok II 350 Starter Rod Short	JT4020M1
908-4313	2.59 M / SPLK 350 M	SplineLok II 350 Starter Rod Long	JT4020M1
908-4376	2.10 M / SPLK 350 M	SplineLok II Starter Rod Long	JT40
908-4315	#700 M / SPLK 350 M	SplineLok II Starter Rod Long	JT40
908-4300	2.72 DS M / SPLK 350 M	SplineLok II 350 Starter Rod Short	AT30
908-4301	2.52 SS M / SPLK 350 M	SplineLok II 350 Starter Rod Short	AT30
908-4174	#250 F / SPLK 350 M	SplineLok II 350 Starter Rod Short	D16X20
908-4182	#400 F / SPLK 350 M	SplineLok II 350 Starter Rod Short	D18X20 / D20X22 / D24X26
908-4113	#402 F / SPLK 350 M	SplineLok II 350 Starter Rod Short	D24X33
908-4111	#600 F / SPLK 350 M	SplineLok II 350 Starter Rod Short	JT24 / JT25 / D24X40
908-4112	#602 F / SPLK 350 M	SplineLok II 350 Starter Rod Short	D33X44 / D36X50
908-4221	#650 F / SPLK 350 M	SplineLok II 350 Starter Rod Short	D33X44 / D36X50
908-4279	#700 F / SPLK 350 M	SplineLok II 350 Starter Rod Short	D36X50 / JT40
908-1721	#400 M / SPLK 350 M	SplineLok II 350 Starter Rod Short	JT1220 / JT20
908-4243	#600 M / SPLK 350 M	SplineLok II 350 Starter Rod Short	JT20
908-4257	#600 M / SPLK 350 M	SplineLok II 350 Starter Rod Short	JT25 / JT30
908-4258	#700 M / SPLK 350 M	SplineLok II 350 Starter Rod Short	D33X44 / D36X50 / JT40
908-4104		Solid Pins	
908-0036		Coiled Pins	
908-4009		O-Ring	



CONNECTORS

Ditch Witch® HDD Tooling offers the widest range of connectors available, so you can adapt to virtually any drilling situation. You'll find exactly what you need to establish solid pin-to-pin or pin-to-box connections. And if you don't, we'll customize a connector to your specifications.

PART NUMBERS	DESCRIPTION	MODEL(S)
369-310	1.21 M / 1.41 F	JT520
369-470	1.21 M / 1.21 M	JT520
908-0804	1.21 M / #200 M	JT520
368-263	1.41 M / 1.94 M	JT920 / JT920L / JT921 / JT922 / JT9 / JT10
908-0806	1.41 M / 2.11 M	JT920 / JT920L / JT921 / JT922 / JT9 / JT10
908-0805	1.41 M / #200 M	JT920 / JT920L / JT921 / JT922 / JT9 / JT10
400-2220	1.41 M / 2.0 M API IF	JT920 / JT922 / JT9 / JT10
400-2222	2.0 F API IF / 1.94 M	JT920 / JT922 / JT9 / JT10
400-2221	2.0 F API IF / 1.41 F	JT920 / JT922 / JT9 / JT10
400-2223	2.0 M API IF / 1.94 F	JT920 / JT922 / JT9 / JT10
368-264	1.69 M / 1.94 M	JT1720M1
906-1783	1.69 F / 2.38 M API R	JT1720M1
908-1707	1.69 M / 2.38 M API R	JT1720M1
906-2562	1.69 M / 2.12 LPT M	JT1720M1
368-261	1.94 M / 1.94 M	JT1720M1 / JT2020 / JT20
369-139	1.94 M / 2.40 M	JT1720M1 / JT2020 / JT20
906-2582	1.94 M / 2.38 M API R	JT1720M1 / JT2020 / JT20
908-0818	1.94 F / 2.11 M	JT1720M1 / JT2020 / JT20
908-1703	1.94 F / 2.38 M API R	JT1720M1 / JT2020 / JT20
908-1708	1.94 M / 2.38 M API R	JT1720M1 / JT2020 / JT20
908-4189	1.94 M / 2.12 LPT F	JT1720M1 / JT2020 / JT20
908-4103	2.38 API R M / 2.12 LPT M	D16X20 / D24X33
400-2570	2.38 API R M / 2.38 API R M	JT1720 / JT2020 / JT20 / JT24 / JT25 / JT2720 / JT3020 / JT30 / D16X20 / D18X20 / D20X22 / D24X26 / D24X33 / D24X40 / D33X44 / D36X50 / JT40
400-1825	2.38 API R F / 2.88 API R M	JT1720 / JT2020 / JT20 / JT24 / JT25 / JT2720 / JT3020 / JT30 / D16X20 / D18X20 / D20X22 / D24X26 / D24X33 / D24X40 / D33X44 / D36X50 / JT40
400-2739	2.38 API R F / 3.5 API IF M	JT1720 / JT2020 / JT20 / JT24 / JT25 / JT2720 / JT3020 / JT30 / D16X20 / D18X20 / D20X22 / D24X26 / D24X33 / D24X40 / D33X44 / D36X50 / JT40
400-2571	2.88 API R M / 2.88 API R M	JT4020 / D24X26 / D24X40 / D36X50 / D50X100 / D55X10 / JT40
400-567	2.59 F / 2.40 M	JT4020
400-1676	2.59 F / 2.88 M API R	JT4020
400-568	2.59 F / 3.50 F API R	JT4020
400-576	2.59 F / 3.27 M	JT4020
908-4226	2.59 F / 2.38 M API R	JT4020
908-4004	2.38 F API R / 2.59 M	JT4020
400-035	3.5 IF M / 3.5 IF M	JT4020 / D24X26 / D24X40 / D36X50 / D50X100 / D55X10 / DD110 / JT40



QUICK CONNECT SYSTEMS



CONNECTORS

PART NUMBERS	DESCRIPTION	MODEL(S)
400-016	2.88 M API IF / 2.88 M API R	AT4020
400-038	2.88 M API R / 2.38 M API IF	AT4020
400-040	2.88 M API R / 3.50 M API R	AT4020
400-3048	2.88 API R F / 3.5 API IF M	JT60
400-3049	3.5 F API IF / 2.88 M API R	JT60
400-2308	3.27 F / 2.88 M API R	JT60
400-2307	2.88 F API R / 3.27 M	JT60
400-2230	3.5 F API IF / 3.27 M	JT60 / JT7020 / JT8020 / JT100
401-255	3.27 F / 2.88 M API IF	JT7020 / JT8020 / JT100 / JT60 / AT60
401-256	3.27 F / 3.5 M API R	JT7020 / JT8020 / JT100 / JT60 / AT60
908-5188	3.27 F / 2.88 M API R	JT7020 / JT8020 / JT100
908-5196	3.27 F / 3.5 M API R	JT7020 / JT8020 / JT100
400-1675	3.27 F / 3.5 M API IF	JT7020 / JT8020 / JT100
400-035	3.5 M API IF / 3.5 M API IF	JT7020 / JT8020 / JT100
400-036	3.5 M API IF / 3.5 M API R	JT7020 / JT8020 / JT100
369-472	3.27 F / 3.5 F API R	JT60 / JT7020 / JT8020 / JT100 / AT60
369-257	1.31 F EZ2 / 1.21 M	JT520 / JT5
369-307	1.31 F EZ2 / 1.94 M	JT520 / JT5
369-309	1.31 F EZ2 / 5K Tab	JT520 / JT5
369-311	1.31 F EZ2 / 1.41 F	JT520 / JT5
400-1431	1.31 F EZ2 / 1.10 M	JT520 / JT5
908-0792	1.31 F EZ2 / #200 M	JT520 / JT5
400-064	1.63 F EZ2 / 1.41 F	JT920 / JT920L / JT921 / JT922 / JT9
400-2672	1.31 F EZ2 / 2.0 M	JT520 / JT5
400-068	1.63 F EZ2 / 1.94 M	JT920 / JT920L / JT921 / JT922 / JT9
908-0793	1.63 F EZ2 / 2.11 M	JT920 / JT920L / JT921 / JT922 / JT9
400-2218	1.63 F EZ2 / 2.0 M API IF	JT920 / JT920L / JT921 / JT922 / JT9
400-920	1.88 F EZ3 / 1.94 M	JT1220M1
401-006	1.88 F EZ3 / 1.94 F	JT1220M1
908-0808	1.88 F EZ3 / 2.11 M	JT1220M1
908-0816	1.88 F EZ3 / 2.38 M API R	JT1220M1
400-2188	1.88 F EZ3 / 2.0 M API IF	JT1220M1
369-999	2.0 F EZ / 1.94 M	JT1720M1 / JT2020 / JT20
400-615	2.0 F EZ2 / 1.94 F	JT1720M1 / JT2020 / JT20
400-824	2.0 F EZ2 / 2.59 M	JT1720M1 / JT2020 / JT20
400-2201	2.0 F EZ2 / 2.0 M API IF	JT1720M1 / JT2020 / JT20
908-1706	2.0 F EZ2 / 2.38 M API R	JT1720M1 / JT2020 / JT20
400-1050	2.25 F EZ3 / 1.94 M	JT1720M1 / JT2020 / JT20
400-1010	2.25 F EZ3 / 2.59 M	JT24 / JT25 / JT3020 / JT30
400-309	2.25 F EZ2 / 2.59 M	JT2720M1
401-340	2.25 F EZ2 / 2.4 M	JT2720M1
908-4235	2.25 F EZ2 / 2.38 M API R	JT24 / JT25 / JT3020 / JT30
908-4225	2.25 F EZ3 / 2.38 M API R	JT24 / JT25 / JT3020 / JT30



CONNECTORS

PART NUMBERS	DESCRIPTION	MODEL(S)
400-091	2.63 F EZ2 / 3.27 M	JT4020 / JT40
400-1417	2.63 F EZ2 / 2.88 M API R	JT4020 / JT40
400-094	2.63 F EZ2 / 2.59 M	JT4020 / JT40
400-2392	2.85 6F EZ2 / 2.88 M API R	AT40 / JT60
400-2394	2.85 6F EZ2 / 3.50 M API IF	AT40 / JT60
400-2395	2.85 6F EZ2 / 3.27 M	AT40 / JT60
368-813	3.5 F EZ2 / 3.27 M	JT60 / JT7020 / JT8020 / JT100
400-1480	3.5 F EZ / 3.50 M API IF	JT7020 / JT8020 / JT100
400-2277	3.5-F EZ / 2.88 M API R	JT60
368-813	3.5-F EZ / 3.27 M	JT60
908-0817	#200 F / 2.11 M	JT520 / JT5 / JT922 / D6X6 / D7X11 / D9X13
908-0701	#200 M / 2.0 M API IF	JT520 / JT5 / JT922 / D6X6 / D7X11 / DX913
908-1701	#250 F / 2.38 M API R	JT1220 / D16X20
908-1724	#400 M / 2.0 M API IF	JT1220 / JT2020 / D18X20 / D20X22 / D24X26
908-1725	#400 M / 2.38 M API R	JT1220 / JT2020 / D18X20 / D20X22 / D24X26
908-1726	#400 M / 1.94 M	JT1220 / JT2020 / D18X20 / D20X22 / D24X26
908-1704	#400 F / 2.38 M API R	JT1220 / JT2020 / JT20 / D18X20 / D20X22 / D24X26
908-4228	#402 F / 2.38 M API R	D24X33
908-4196	#600 F / 2.88 M API R	JT2020 / JT20 / JT24 / JT25 / JT3020 / JT30 / D24X40
908-4224	#600 F / 2.38 M API R	JT2020 / JT20 / JT24 / JT25 / JT3020 / JT30 / D24X40
908-1727	#600 M / 1.94 M	JT2020 / JT20 / JT24 / JT25 / JT3020 / JT30 / D24X40
908-4002	#600 M / 2.38 M API R	JT2020 / JT20 / JT24 / JT25 / JT3020 / JT30 / D24X40
908-4003	#600 M / 2.59 M	JT2020 / JT20 / JT24 / JT25 / JT3020 / JT30 / D24X40
908-4197	#602 F / 2.88 M API R	D33X34 / D36X50
908-4233	#602 F / 2.38 M API R	D33X34 / D36X50
908-4234	#650 F / 2.38 M API R	D33X34 / D36X50
908-4242	#700 F / 2.38 M API R	D36X50
908-5199	#800 F / 3.50 M API R	JT7020 / JT8020 / JT100 / D80X100
908-5210	#800 F / 3.50 M API IF	JT7020 / JT8020 / JT100 / D80X100
908-5002	#800 M / 2.88 M API R	JT7020 / JT8020 / JT100 / D80X100
908-5186	#800 F / 2.88 M API R	JT100
908-5004	#800 M / 3.5 M API IF	JT7020 / JT8020 / JT100 / D80X100
908-5005	#800 M / 3.27 M	JT7020 / JT8020 / JT100 / D80X100
908-5205	#802 F / 3.50 M API R	D80X120 / D100X120 / DD110
908-5211	#802 F / 3.50 M API IF	D80X120 / D100X120 / DD110
908-5195	#802 F / 2.88 M API R	D80X120 / D100X120 / DD110
908-5184	#900 F / 2.88 M API R	D50X100 / D80X100
908-5200	#900 F / 3.50 M API R	JT60 / D50X100 / D80X100
908-5214	#900 F / 3.50 M API IF	JT60 / D50X100 / D80X100
908-5190	#1000 F / 2.88 M API R	D80X120 / D100X120 / DD110
908-5207	#1000 F / 3.50 M API R	D80X120 / D100X120 / DD110
908-5213	#1000 F / 3.50 M API IF	D80X120 / D100X120 / DD110